





















Descripción	Description	Descritivo		Ref	€	
Cuchara Mesa	Table Spoon	Colher Mesa		32001		12
Tenedor Mesa	Table Fork	Garfo Mesa		32002		12
Cuchillo Mesa	Table Knife	Faca Mesa		32003		12
Cuchara Postre	Dessert Spoon	Colher Sobremesa		32004		12
Tenedor Postre	Dessert Fork	Garfo Sobremesa		32005		12
Cuchillo Postre	Dessert Knife	Faca Sobremesa		32006		12
Pala Pescado	Fish Knife	Faca Peixe		32012		12
Tenedor Pescado	Fish Fork	Garfo Peixe		32013		12
Cuchara Café	Tea Spoon	Colher Cha		32007		12
Cuchara Moka	Coffee Spoon	Colher Cafe		32008		12
Tenedor Lunch	Cake Fork	Garfo Bolo		32009		12
Cazo Sopa	Soup Ladle	Colher Terrina		32016		1
Cucharon Legumbre	Serving Spoon	Colher Arroz		32014		1
Pala Pastel	Cake Server	Pa Bolo		32025		1
Pala Servir Pescado	Fish Serving Knife	Faca Trinchar Peixe		32022		1
Tenedor Servir Pescado	Fish Serving Fork	Garfo Trinchar Peixe		32023		1
Cubertería 24 Pzs SIN Estuche	24 Pcs Cutlery Set without Box	Faqueiro 24 Pçs SEM Caixa		35032		1
Cubertería 75 Pzs SIN Estuche	75 Pcs Cutlery Set without Box	Faqueiro 75 Pçs SEM Caixa		35332		1
Cubertería 113 Pzs SIN Estuche	113 Pcs Cutlery Set without Box	Faqueiro 113 Pçs SEM Caixa		35532		1